

PXE Client configuration

The clients have to be set up in order to boot from the PXE server and not from the internal flash storage or HDD.

For CXP modules the network boot option in the BIOS has to be activated. In most cases that is enough.

The Apalis and Colibri modules must have an u-boot that supports booting over network (version and higher). And some things have to be set in the u-boot environmentals as described below.

Christmann Apalis Exynos

Toradex Apalis T30

Toradex Colibri T20

From:

<https://recswiki.christmann.info/wiki/> - RECS®|Box Wiki

Permanent link:

https://recswiki.christmann.info/wiki/doku.php?id=documentation:client_side&rev=1435925873

Last update: **2015/07/03 12:17**

