# **Opening/closing the case**

To open the case first make sure, that **no heavy load** is on the modules. Because this can lead to an overheating when the top cover is removed.

### Antares

#### **Opening the case**

First unscrew the M3 knurled screw at the top back of the Antares. Then slide the cover back and carefully lift the cover so that the hooks don't get stuck and bend.

#### **Closing the case**

Place the cover onto the Antares so that the hooks fit into the holes in the chassis. Then slide the cover to the front while pushing the hooks downwards into the holes if they are stuck. At last tighten the M3 knurled screw at the top back of the Antares.

## Arneb

#### **Opening the case**

Unscrew the 16 (six on top; eight on the sides) M3 screws using a T8 Torx screwdriver and lift the cover.

#### **Closing the case**

Place the cover on top of the Arneb and check if the screwholes of the cover align with the ones in the chassis.

If this is not the case the cover is placed in the wrong direction. Tighten all 16 screws using a T8 Torx screwdriver.

From: https://recswiki.christmann.info/wiki/ - RECS<sup>®</sup>|Box Wiki

Permanent link: https://recswiki.christmann.info/wiki/doku.php?id=documentation:opening\_closing\_the\_case&rev=1415013225

Last update: 2014/11/03 11:13

