

Physical interface

Front panel connectors

The following items are located at the front of a RECS®|Box Deneb and Durin:

- Power button
- Graphical display
- Joystick with push function
- Two USB ports that can be switched to every module via KVM
- One HDMI port that can be switched to every module via KVM

Control panel

The display on the front panel of the RECS®|Box shows the status of the unit on multiple screens that automatically change every couple of seconds and are updated live.

Power connectors

Deneb

The Deneb has four male C14 jacks on the back that can be connected to an 230V power outlet using a standard C13 cable.

The exhaust air openings in the back must be kept free. Keep that in mind when installing cables behind the Deneb.

Durin

The Durin has two male C14 jacks on the back that can be connected to an 230V power outlet using a standard C13 cable.

The exhaust air openings in the back must be kept free. Keep that in mind when installing cables behind the Deneb.

Sensors

From:

<https://recswiki.christmann.info/wiki/> - RECS®|Box Wiki

Permanent link:

https://recswiki.christmann.info/wiki/doku.php?id=doc_recs4:physical_interface&rev=1583328511

Last update: **2020/03/04 13:28**

