

# Expansion header pinout

Signal	Pin Nr.	Pin Nr.	Signal
3.3 V	1	2	5 V
<b>Jetson I2C SDA</b> , SMARC I2C SDA, SMARC GPIO 1	3	4	5 V
<b>Jetson I2C SCL</b> , SMARC I2C SCL, SMARC GPIO 0	5	6	GND
SMARC GPIO 2	7	8	
GND	9	10	
	11	12	
SMARC GPIO 4	13	14	GND
SMARC GPIO 8	15	16	Jetson GPIO 3
3.3 V	17	18	Jetson GPIO 5
	19	20	GND
	21	22	Jetson GPIO 6
	23	24	
GND	25	26	
SMARC GPIO 9	27	28	Jetson GPIO 11
SMARC GPIO 10	29	30	GND
SMARC GPIO 11	31	32	Jetson GPIO 13
SMARC GPIO 12	33	34	GND
	35	36	
SMARC GPIO 13	37	38	
GND	39	40	

From:

<https://recswiki.christmann.info/wiki/> - RECS®|Box Wiki

Permanent link:

[https://recswiki.christmann.info/wiki/doku.php?id=doc\\_urecs:physical\\_interface&rev=1712313027](https://recswiki.christmann.info/wiki/doku.php?id=doc_urecs:physical_interface&rev=1712313027)

Last update: **2024/04/05 10:30**

