

Server installation

The following chapter will give you an overview on how to install an maintain your RECS®|Box. When working on the RECS®|Box always wear **ESD protection** equipment.

Carrier replacement

When removing a Carrier always **work very carefully** and **do not bend** the baseboards **nor use greater force** to get them into place.

Compute module installation

When changing a module shut down all modules on the respective carrier and turn the power for the modules off in the managemant GUI. The rest of the system can stay powered.

SMARC module

Nvidia Jetson module

M.2 card installation

Fan replacement

A fan that has damaged blades schould be **replaced immediately**, because the bearing will break very fast due to the imbalance and resulting vibrations.

When changing a fan on a working system watch out that the system is not overheating during the changing process.

From:

<https://recswiki.christmann.info/wiki/> - RECS®|Box Wiki

Permanent link:

https://recswiki.christmann.info/wiki/doku.php?id=doc_urecs:server_installation&rev=1643802803

Last update: 2022/02/02 11:53

