

Server installation

The following chapter will give you an overview on how to install and maintain your u.RECS®. When working on the u.RECS® always wear **ESD protection** equipment.

Compute module installation

When changing a module shut down all modules on the respective carrier and turn the power for the modules off in the management GUI. The rest of the system can stay powered.

SMARC module

Nvidia Jetson Xavier NX module

M.2 card installation

Fan replacement

A fan that has damaged blades or any other kind of damage should be **replaced immediately**. Fans can only be changed opening the u.RECS chassis. Please power down the whole system and disconnect power to not risk any damage due to shortcuts etc.

From:
<https://recswiki.christmann.info/wiki/> - RECS®|Box Wiki

Permanent link:
https://recswiki.christmann.info/wiki/doku.php?id=doc_urecs:server_installation&rev=1727788911

Last update: **2024/10/01 13:21**

