

Opening/closing the case

To open the case first make sure, that **no heavy load** is on the modules. Because this can lead to an overheating when the top cover is removed.

Antares

Opening the case

First unscrew the M3 knurled screw (marked red) at the top back of the Antares. Then slide the cover back (marked orange) and carefully lift the cover so that the hooks don't get stuck and bend.

Closing the case

Place the cover onto the Antares so that the hooks fit into the holes in the chassis. Then slide the cover to the front (marked orange) while pushing the hooks downwards into the holes if they are stuck.

At last tighten the M3 knurled screw (marked red) at the top back of the Antares.



Fig. 1

Arneb

Opening the case

Unscrew the 14 (six on top; eight on the sides; marked red below) M3 screws using a T8 Torx screwdriver and lift the cover.

Closing the case

Place the cover on top of the Arneb and check if the screwholes of the cover align with the ones in the chassis.

If this is not the case the cover is placed in the wrong direction. Tighten all 14 screws (marked red below) using a T8 Torx screwdriver.




Fig. 2: Cover screws (red circle)

From:
<https://recswiki.christmann.info/wiki/> - RECS®|Box Wiki

Permanent link:
https://recswiki.christmann.info/wiki/doku.php?id=documentation:opening_closing_the_case&rev=1415021936

Last update: **2014/11/03 13:38**

