

User Manual

1. Introduction
 1. Overview
 1. Device types
 2. CPU Modules
 2. Safety instructions
 3. Cluster architecture
2. Server installation
 1. Rack mounting
 2. Opening/closing the case
 3. Baseboard replacement
 4. Compute module installation
 5. Netboard installation
 6. Extension card installation
 7. Fan replacement
3. Physical interface
 1. RCU interface
 1. Front panel connectors
 2. Control panel
 3. Power connectors
 2. RPU interface
 1. Front panel connectors
 2. LCD display
 3. Power connectors
 3. Sensors
4. Software interface
 1. Management WebGUI
 1. Management
 2. Global settings
 3. Log viewer
 2. REST API
 3. Nagios API
5. PXE Server
 1. Server Side
 2. Client Side
6. Glossary

From:
<https://recswiki.christmann.info/wiki/> - RECS®|Box Wiki

Permanent link:
https://recswiki.christmann.info/wiki/doku.php?id=documentation:user_manual&rev=1435915411

Last update: **2015/07/03 09:23**

