

RPU interface

Front panel connectors

LCD display

Welcome LCD screen: line1= RECS Box RCU|line2=192.168.13.50 Power usage screen:

Power connectors

From:

<https://recswiki.christmann.info/wiki/> - RECS®|Box Wiki

Permanent link:

https://recswiki.christmann.info/wiki/doku.php?id=documentation:rpu_interface&rev=1414757362

Last update: **2014/10/31 12:09**

